

Cemintel Constructafloor

External and internal wet area waterproofing

26-08-2019

Howard Tse

CSR Lightweight Systems, NSW

T: (02) 9844 7872

M: 0466 825 169

E: HTse@csr.com.au



Parchem Construction Supplies Pty Ltd

Head Office

7 Lucca Road, Wyong NSW 2259

P: 02 4350 5000 | F: 02 4351 2024

www.parchem.com.au

ABN 80 069 961 968

Mr Tse,

Thank-you for your enquiry.

For sheeted floors both internal and external we suggest the following products and steps.

1. Nitoseal PU250 as joint sealant
2. Primer 115 for non-porous material (sheeting) & Primer 120 for Porous (concrete and brick)
3. Apply 1st coat Nitoproof 810 at minimum WFT – see TDS
4. Lay in Nitoband tape to Wet membrane 810 at all floor joints, wall to floor joints & wall joints to termination level.
5. Wet out Nitoband tape with Nitoproof 810
6. Allow to dry prior to second application, 2nd coat Nitoproof 810 to minimum required Total WFT

Please contact me with any questions.

Yours sincerely

PARCHEM CONSTRUCTION SUPPLIES PTY LTD

Gary Bennett

Engineer Specification Manager | Parchem Construction Supplies Pty Ltd



M 0412 124 264 T 1300 737 787 W www.parchem.com.au

E gary.bennett@parchem.com.au,

DuluxGroup, 64 Elizabeth Street Wetherill Park, NSW 2164